

Suction Lifter Maintenance

Here are a few essential steps to keep your handheld suction lifter in good condition:

1. Regular Inspection

Before each use, check the pump*, seal, and suction cup for any damage or wear.

2. Clean the Suction Cup

Wipe the cup with a lint-free cloth and mild soap to remove dust, dirt, or debris that could affect suction.



3. Remove Dust

Use a soft brush to remove dust in the the grooves around the pad rim.



4. Lubricate Moving Parts*

Apply a small amount of silicone lubricant to the pump mechanism if recommended by the manufacturer.



5. Check for Air Leaks*

Pump the handle and ensure the vacuum holds for an extended period without losing grip.

6. Store Properly

Keep the lifter in a clean, dry place, away from extreme temperatures and direct sunlight.

7. Replace Worn Parts

If the rubber seal or suction cup shows signs of deterioration, replace them promptly to maintain performance.

**Only applies to pump action suction lifters*

Following these steps will help keep your suction lifter working efficiently and safely.