





# REVEGO

Pocket systems for new space concepts





# We are Lincoln Sentry

The tradie's choice  
for specialty hardware



From our humble beginnings in Brisbane more than 30 years ago, Lincoln Sentry's reputation has continued to grow and evolve as one of Australia's leading distributors of world class speciality hardware and smart solutions to the commercial, new home and renovation sectors.

We love the trade. It's why we're so passionate about the industry and the partnerships we have with you – the expert craftsmen and design specialists who transform ordinary spaces into the extraordinary.



## EXTENSIVE PRODUCT RANGE

Offering a diverse product portfolio sourced from across the globe and locally within Australia, we are committed to providing high quality specialty hardware solutions that help you create exciting spaces that shape the way people interact with where they work, live and play.

## EXPERT SUPPORT

Whether you're a cabinetmaker, shopfitter, joiner, security fabricator, glazier or designer, our dedicated National Customer Support Centre (NCSC) and technical specialists are the experts you can count on. Problem solvers at heart, their expert knowledge and advice enables you to bring your smart and functional ideas to life.



With boots on the ground in 25 locations and counting, we're local and always close by to assist you with the best products, technical advice and support on offer.

And, our Online Store at [www.lincolnsentry.com.au](http://www.lincolnsentry.com.au) brings us even closer with fast access to Australia's largest range of cabinet and architectural hardware products from wherever you are, whenever it's convenient for you.

The Blum logo, featuring a stylized white arrow pointing upwards and to the right, followed by the word "blum" in a bold, lowercase, sans-serif font. A registered trademark symbol (®) is located at the top right of the word.

reddot winner 2022



More and more people are merging their kitchen, dining, living and working space. This trend places high demands on modern living concepts. Pocket systems make it possible to quickly, easily and intuitively open up entire spaces when needed, and close them off again when not in use. This gives you totally new design possibilities for a variety of areas and applications.

With the new pocket systems product category, Blum has developed the solution for the optimum use of space – REVEGO is a unique pocket door system with fully integrated technology, all packaged inside a dedicated narrow cabinet: the pocket.

Contents

02	Lincoln Sentry
12	Planning & Product Selection
14	REVEGO duo - Double Door
26	REVEGO uno - Single Door
31	REVEGO uno+uno - Two Single Doors
36	REVEGO uno+duo - Single & Double Door
52	REVEGO duo+duo - Two Double Doors
64	Calculations & Assembly
70	Assembly Devices



### Efficient manufacturing

Thanks to the unique full integration of the fittings in the pocket construction, REVEGO already comprises all the necessary components. You can easily pre-assemble pocket systems in your workshop and transport them to end users in a carefully packaged state. This makes installation on site easier and increases efficiency.



Experience full-size REVEGO.  
Download the AR application and get started:  
[www.blum.com/revarapp](http://www.blum.com/revarapp)



### Rapid on-site installation

Final assembly on site is simplicity itself: set up, align and mount the pockets; install the doors and track; make adjustments to the gap layout – and that's it! The 3-dimensional adjustment options are easily accessible and intuitive to use. And thanks to the integrated service interface, it is really simple to remove the fittings – even in installed furniture.



### Easy planning

Standardised pocket widths of 100 mm for the single door REVEGO uno and 150 mm for the double door REVEGO duo permit unrestricted design possibilities around the pocket. Single and double door applications can be individually combined.



### The ultimate in convenience

No need for handles thanks to TIP-ON motion technology; users can open cabinet doors with a single touch and slide them away completely into the pocket. To close off the space, the user simply presses the door to release it from the pocket and then presses it again to elegantly conceal the entire area.



## REVEGO at a glance

- Faster and easier installation thanks to pre-assembly of fittings parts
- Unique full integration of fittings in pocket construction
- Easy planning thanks to predefined pocket widths
- Enhanced ease and mesmerising motion
- Individual design possibilities through the combination of REVEGO uno (1) and REVEGO duo (2)
- Different nominal lengths allow you to adapt applications to the installation situation
- Smooth opening and closing without a handle thanks to integrated TIP-ON motion technology
- Can be implemented with or without a plinth option
- Precise and easily accessible 3-dimensional adjustment options
- Full overlay fronts completely conceal the pocket when closed for a perfect gap layout
- Pocket systems can be used in all living areas
- Suitable for solutions with internal- or cabinet construction, or as a walk-in application such as dressing rooms, pantries, etc.
- Fittings can be easily removed (even from built-in furniture) thanks to an integrated service interface

## Overview of applications and planning notes

### REVEGO duo

#### Double door, right or left



Page 14

- Number of fronts: 2
- Installation width: 900 to 1500 mm
- Internal width within the application: up to 1350 mm
- Front width: 442 – 748 mm

### REVEGO uno

#### Single door, right or left



Page 26

- Number of fronts: 1
- Installation width: 450 to 900 mm
- Internal width within the application: up to 800 mm
- Front width: 442 – 898 mm

### REVEGO uno + duo

#### Single door and double door combined



Page 36

- Number of fronts: 3
- Installation width: 1350 to 2400 mm
- Internal width within the application: up to 2150 mm
- Front width: 442 – 748 mm and 442 – 898 mm

### REVEGO duo + duo

#### Two double doors combined




Page 52

- Number of fronts: 4
- Installation width: 1800 to 3000 mm
- Internal width within the application: up to 2700 mm
- Front width: 442 – 748 mm

### Easy product selection

Blum's Product Configurator makes it easy for you to choose your products and provides checked parts lists, planning information and CAD data.



# Blum services at a glance

Blum services support you throughout your entire process – from planning and design all the way through to manufacturing. Take advantage of Blum's tried-and-tested and user-friendly services for your projects with REVEGO.



## Concept, planning and product selection

Blum's Product Configurator will help you select the right products quickly and efficiently. It gives you checked parts lists and planning information, as well as accurate production drawings.



## Design

You can export REVEGO projects in various CAD formats for use in your own design software.



Together with selected partners, Blum have also established interfaces for the straightforward transfer of data and completion of your project in your design software.



## Ordering

Simply transfer your parts lists from the Product Configurator directly to the online store at [www.lincolnsentry.com.au](http://www.lincolnsentry.com.au) for easy ordering. Your REVEGO configurations are easily saved to "My projects", where you can then manage your customer projects.



## Manufacturing

Speed up your production process with Blum's Product Configurator. Transfer the planning results to MINIPRESS top with EASYSTICK (using BXF) or directly to your CNC machine. In order to transfer the data to your CNC machine, you'll receive specially prepared CAM data (CAM DXF or complete WOP drilling programs) in the Product Configurator. This makes production processes on the CNC machine even quicker and easier.




Find out more about our  
E-SERVICES:  
[www.blum.com/configurator](http://www.blum.com/configurator)



Register now free of charge to  
take advantage of E-SERVICES.  
[e-services.blum.com](http://e-services.blum.com)

## Planning approach and product selection



EB	Installation width
LWA	Internal width within the application
FB	Front width

### Niche installation

Planning approach from the outside moving inwards with fixed installation width for the entire application. The available space determines the installation width and is decisive for the possible number of fronts, front widths and thus for the primary application selection. The respective fittings parts and cabinet dimensions within the application can be calculated in the next step.

1. What recess width is available for the application? The recess width is the installation width for the application.
2. Determine the possible number of fronts and front width based on the installation width. This will determine the type of application.
3. The pocket dimensions, front protrusion and internal dimensions can now be defined on the planning pages of the respective application, and the further fittings selection can be made.

### Free-standing installation

Planning approach starting from the inside moving out with focus on the cabinet width and construction inside the application. The cabinets to be concealed are the decisive factor for the possible number of fronts, front widths and thus for the primary application selection. The installation dimensions and the respective fittings parts are calculated in the next step.

1. What is the cabinet width that needs to be concealed? The cabinet width is the internal width within the application.
2. Determine the possible number of fronts and front width based on the internal cabinet width. This will determine the type of application and its installation width.
3. The pocket dimensions and front protrusion can now be defined on the planning pages of the respective application, and the further fittings selection can be made.

### Number of fronts


Planning approach with a predefined number of fronts and fixed front widths. The number of fronts determines the primary application selection. The predefined front widths are crucial for the installation width of the entire application. The respective fittings parts and cabinet dimensions within the application can be calculated in the next step.

1. What number of fronts was selected?  
The number of fronts defines the type of application.
2. Desired front widths plus gaps determine the installation width.
3. The pocket dimensions, front protrusion and internal dimensions can now be defined on the planning pages of the respective application, and the further fittings selection can be made.


# Planning approach and product selection

## Functional area

### REVEGO uno




### REVEGO duo



A minimum distance to the nearest element in front of the pocket must be kept free for safety reasons: front width + at least 300 mm

- FB Front width
- POT Pocket depth


## Nominal length, front width, front protrusion and depth requirement



The minimum front protrusion results from the combination of nominal length, front width and the TIP-ON trigger path (AW) when using standard nominal lengths. By cutting the profiles to size, the front protrusion (FU) can be customised (min. FU = 7 mm).

$$FU = FB - NL + AW$$

- AW TIP-ON trigger path
- FB Front width
- FU Front protrusion
- NL Nominal length



The depth requirement is the pocket depth (POT) and is determined by the nominal length + 100 mm, plus the pocket back.

- NL Nominal length
- POT Pocket depth
- PORW Pocket back

## Note

- The internal dimensions in the application (width x height x depth) determine the maximum space to be planned for the internal construction.
- Design the widest front first for combined applications.
- Certified durability of 40,000 opening and closing cycles.
- The manual operating force is less than 70 N according to the durability test.
- Drilling patterns, cut-to-size dimensions and detailed parts lists can be found in the Product Configurator.


## Assembly

- You will need a CNC machine or MINIPRESS top with EASYSTICK from Blum to machine the wooden parts. Please note that both horizontal drillings and a track cut-out will be needed.
- We recommend using the drilling template for REVEGO pocket connectors for the horizontal drillings.
- See appendix for calculation and assembly information for cutting profiles to size.



Installation position	Double door, right or left (mm)		
	Width	Height	Depth
Installation dimensions	900 – 1500	1820 – 3012	From 575
Internal dimensions within the application	Width up to 1350	Height up to 2884	Depth From 484
Pocket dimensions	Width 150	Height 1807 – 2999	Depth From 554
Front dimensions	Width 442 – 748	Height 1800 – 2980	Thickness 18 – 26
Front weight	35 kg per front		

Overview



EB	Installation width
FB	Front width
LTR	Track
LTB	Track cover panel
POH	Pocket height
POIS	Internal pocket side
PORW	Pocket back
POT	Pocket depth
SS	Optional partition side
ZB	Fixed shelf
7d	Door support on partition side
7e	Door support for decor panel/cabinet side



Fittings selection made easy

It is easy to work out the fittings and drilling positions you need using the Product Configurator. Scan the QR code, enter the webcode in the Product Configurator or click on the short URL. Don't have login information for E-SERVICES yet? Register here and get access free of charge.

Webcode

DQITIM


Link

[www.blum.com/DQITIM](http://www.blum.com/DQITIM)



Product Configurator

**Component overview**




**Consisting of:**

1a	Top pocket profile
1b	Bottom pocket profile
1c	Roller profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
2f	Hinge bracket
2i	Pocket cover strip incl. mounting
3a/4a	Front pocket connector
3b/4b	Back pocket connector
Z	Scuff guard

Component overview

Front




Consisting of:

2a	Hinge strip
2b	Double door hinge
2c	Roller carriage hinge
2d	TIP-ON unit door
2e	Support for door cover strip
2j	Door cover strip
2k	Mounting for door cover strip
7e	Door support for decor panel/cabinet side

A We recommend at least one alignment fitting per front with a maximum installation height of 20 mm. Ensure collision-free installation for folded pair of fronts.

Component overview



Consisting of:

2i	Pocket cover strip incl. mounting
6a	Track
6b	Roller carriage
6c	Roller carriage transporter
6d	Mounting for track cover panel
6e	Catch plate
6f	Spacer
7a	Track fixing
7b	Cover for track fixing
7c	Pin for track fixing

## Ordering information

1	Pocket profile set with TIP-ON		Blum No		Code	
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right	Left	Right
	450	550	802P450D.L2	802P450D.R2	7115194	7115195
	525	625	802P525D.L2	802P525D.R2	7115196	7115197
	600	700	802P600D.L2	802P600D.R2	7115198	7115199
	675	775	802P675D.L2	802P675D.R2	7115200	7115201
	750	850	802P750D.L2	802P750D.R2	7115202	7115203

\* Specification without pocket back. A back construction with a thickness of at least 3 mm is required. Pocket and roller profiles as well as TIP-ON unit pocket can be shortened to a custom nominal length.

## Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1c	1 x	Roller profile
1d	1 x	TIP-ON unit pocket
1e	6 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip

2	Hinge bracket set with TIP-ON		Blum No		Code	
	Pocket height (mm)		Left	Right	Left	Right
	1807 – 1956		802T1000.L2	802T1000.R2	7115204	7115205
	1957 – 2106		802T2000.L2	802T2000.R2	7115206	7115207
	2107 – 2256		802T3000.L2	802T3000.R2	7115208	7115209
	2257 – 2406		802T4000.L2	802T4000.R2	7115210	7115211
	2407 – 2556		802T5000.L2	802T5000.R2	7115212	7115213
	2557 – 2706		802T6000.L2	802T6000.R2	7115214	7115215
	2707 – 2856		802T7000.L2	802T7000.R2	7115216	7115217
	2857 – 2999		802T8000.L2	802T8000.R2	7115218	7115219

Door cover strips must be shortened to a specific length

## Consisting of:

2a	1 x	Hinge strip
2b	5 x	Double door hinge
2c	1 x	Roller carriage hinge
2d	1 x	TIP-ON unit door
2e	1 x	Support for door cover strip
2f	1 x	Hinge bracket
2i	1 x	Pocket cover strip incl. 5 x mountings, black anodised
2j	1 x	Door cover strip, black anodised
2k	6 x	Mounting for door cover strip

Ordering information

Pocket connector set						
3	Application with plinth			Blum No		Code
	Pocket side thickness (mm)	Colour				
	15 – 17	Black	802V560B	7115220		
	18 – 19	Black	802V580B	7115221		
Pocket connector top + bottom: POVH 10 mm for 0 – 6 mm gap						
POVH Pocket connector height						
Consisting of:						
3a	2 x	Front pocket connector				
3b	2 x	Back pocket connector				

Pocket connector set						
4	Application without plinth		Blum No		Code	
	Pocket side thickness (mm)	Colour	Left	Right	Left	Right
	15 – 17	Black	802V660B.L1	802V660B.R1	7115222	7115223
	18 – 19	Black	802V680B.L1	802V680B.R1	7115224	7115225
Pocket connector top: POVH 10 mm for 0 – 6 mm gap						
Pocket connector bottom: POVH 3 mm for gap from 7 – 13 mm						
POVH Pocket connector height						
Consisting of:						
4a	2 x	Front pocket connector				
4b	2 x	Back pocket connector				

6	Track set		Blum No		Code	
	LWA double door (mm)	Colour	Left	Right	Left	Right
	1050	Black anodised	802L1050DL1	802L1050DR1	7115177	7115178
	1200	Black anodised	802L1200DL1	802L1200DR1	7115179	7115180
	1250	Black anodised	802L1250DL1	802L1250DR1	7115181	7115182
	1350	Black anodised	802L1350DL1	802L1350DR1	7115183	7115184
Track can be shortened to any length.						
LWA Internal width within the application						
Consisting of:						
6a	1 x	Track				
6b	1 x	Roller carriage				
6c	1 x	Roller carriage transporter				
6d	2 x	Mounting for track cover panels				
6e	1 x	Catch plate, black				
6f	2 x	Spacer				

7	Assembly set for one double door		Blum No		Code	
	Colour		Left	Right	Left	Right
	Black		802M0002.L2	802M0002.R2	7115185	7115186
Consisting of:						
7a	1 x	Track fixing				
7b	1 x	Cover for track fixing				
7c	2 x	Pin for track fixing				
7d	1 x	Door support on partition side (can be selected depending on installation situation)				
7e	1 x	Door support for decor panel/cabinet side incl. attachment (can be selected depending on installation situation)				

## Ordering information


Z	Accessories		
<b>Scuff guard</b>			
	For front thicknesses starting from 23 mm	Blum No	Code
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection	802ZA00S	7115226
<b>Consisting of:</b>			
3 x	External pocket side scuff guard		
2 x	Internal pocket side scuff guard		
<b>Screws</b>			
	6 x 14.5 mm system screws, nickel plated	Pack quantity: 1000	Blum No Code
		661.1450.HG	7115105

EXPANDO T – for thin fronts		Blum No	Code
	EXPANDO T – single	70T4532T	7102466
EXPANDO T suitable for thin fronts – see page 67			
For front thicknesses less than 18 mm, we recommend a trial application			
Screws are not included in the scope of delivery			

Alignment/adjustment fitting for distorted doors		Code
	Alignment/adjustment fitting – Aluminium <ul style="list-style-type: none"> <li>• For door / front thicknesses of 18-30 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• Length of the adjustment fitting 1990 mm, can be shortened as required.</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>	7113636
	Alignment/adjustment fitting – Plastic <ul style="list-style-type: none"> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>	7113858

Please refer to the Lincoln Sentry website for installation instructions and drilling information.

**Planning**




<b>Installation width/internal width within the application</b>		EB	Installation width
Without partition side: EB = LWA + POB (150 mm)		ET	Installation depth
With partition side: EB = LWA + POB (150 mm) + SS		Fsl	Gap left
<b>Front width/front protrusion</b>		Fsr	Gap right
FB = (EB - Fsl - Fsm - Fsr) : 2 (fronts)		Fsm	Centre gap (between the fronts)
Fsl/Fsr = 1.0 – 4.0 mm; Fsm = 2.0 – 8.0 mm		FB	Front width
Max. NL = FB + 8 mm		FD	Front thickness
FU = FB - NL + 15 mm		FS	Front gap
(min. FU = 7 mm)		FU	Front protrusion
<b>Installation depth/pocket depth</b>		LWA	Internal width within the application
ET = POT + FS (2 mm) + FD		NL	Nominal length
FD = 18 – 26 mm		POB	Pocket width
Min. POT = NL + POTV (≥ 100 mm) + PORW (≥ 4 mm)		POT	Pocket depth
POSD = 15 - 19 mm		PORS	Pocket back cut
<ul style="list-style-type: none"> <li>- By cutting the profiles to size, the front protrusion (FU) can be customised.</li> <li>- To ensure optimum functionality, the fronts are slightly tilted inside the pocket.</li> <li>- The internal width within the application determines the maximum width to be planned for the internal construction.</li> <li>- With front thicknesses (FD) of more than 23 mm, the side gap (pocket side), the outside front radius and the inner radius of the external pocket side must be at least 3 mm.</li> <li>- For front thicknesses (FD) less than 18 mm (possible depending on material/stability), we recommend a trial application.</li> </ul>		PORW	Pocket back
		POSD	Pocket side thickness
		POTV	Pocket depth loss
		SS	Partition side (optional)



Planning

Installation height, front height

Application with plinth



$$FH = POH - Fo - Fu$$

$$EH \leq POH + POVH \text{ top and bottom}$$

$$POH = FH + Fo + Fu$$

POVH 10 mm: gap 0 – 6 mm

- Note tilt angle when erecting!
- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm
- Minimum plinth height 80 mm

EH Installation height

Fo Top gap

Fu Bottom gap


FH Front height

POH Pocket height

POVH Pocket connector height

Installation height, front height

Application without plinth



$$FH = POH - Fo - Fu$$

$$EH \leq POH + POVH \text{ top and bottom}$$

$$POH = FH + Fo + Fu$$

POVH top 10 mm: gap 0 – 6 mm

POVH bottom 3 mm: gap from 7 – 13 mm

- Note tilt angle when erecting!
- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm

EH Installation height

Fo Top gap

Fu Bottom gap


FH Front height

POH Pocket height

POVH Pocket connector height


Application with set-back plinth

Additional rear pocket connector



Planning


Door support on partition side



- Assembly height of the door support ideally as far down as possible, however up to a maximum height of 1000 mm from the front bottom edge
- Ensure collision-free installation

FS	Front gap
SS	Partition side
7d	Door support on partition side

Door support for decor panel/cabinet side




- Assembly height AS: 64 mm + Fu from the decor panel/cabinet bottom edge
- Assembly height front: 64 mm from the front bottom edge
- Ensure collision-free installation

AS	Decor panel/cabinet side
Fu	Bottom gap
7e	Door support for decor panel/cabinet side

Planning


Track installation dimension



LBH = 83 mm
LBH = 15 - 19 mm (≤ 17 mm the spacer must be used)
LTF = 17 mm
LA = 100 mm
LV = LA + ZBD (≥ 15 mm)
<ul style="list-style-type: none"> <li>- We recommend using a cross member to stabilise the fixed shelf. Minimum distance to front edge of internal pocket side = 170 mm</li> <li>- A solid connection between the fixed shelf and the pocket with connector fittings is recommended for an attractive gap layout</li> <li>- No mounting of add-on parts directly on the track</li> </ul>
FD Front thickness
LA Track cut-out
LV Track installation
LBD Track cover panel thickness
LBH Track cover panel height
LTF Track gap
PORS Pocket back cut
ZBD Fixed shelf thickness

Planning

Internal height and internal depth within the application



$$LHA = POH - LV$$

$$LTA = POT - 70 \text{ mm}$$

- The internal height/internal depth within the application determines the maximum height/depth to be planned for the internal construction

LHA Internal height within the application

LTA Internal depth within the application

LV Track installation


POH Pocket height

POT Pocket depth



Installation position	Single door, right or left (mm)		
	Width	Height	Depth
Installation dimensions	450 – 900	1820 – 3012	From 575
Internal dimensions within the application	Width	Height	Depth
	up to 800	up to 2999	From 519
Pocket dimensions	Width	Height	Depth
	100	1807 – 2999	From 554
Front dimensions	Width	Height	Thickness
	442 – 898	1800 – 2980	18 – 26
Front weight	35 kg per front		

Overview



EB	Installation width
FB	Front width
POH	
POIS	Internal pocket side
PORW	Pocket back
POT	Pocket depth
2h	TIP-ON incl. catch plate



Fittings selection made easy

It is easy to work out the fittings and drilling positions you need using the Product Configurator. Scan the QR code, enter the webcode in the Product Configurator or click on the short URL. Don't have login information for E-SERVICES yet? Register here and get access free of charge.


Web code **DQIU7Y**  
 Link [www.blum.com/DQIU7Y](http://www.blum.com/DQIU7Y)



Product Configurator

Component overview

Pocket




Consisting of:

1a	Top pocket profile
1b	Bottom pocket profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
1h	BLUMATIC unit
2f	Hinge bracket
2i	Pocket cover strip incl. mounting
3a/4a	Front pocket connector
3b/4b	Back pocket connector
Z	Scuff guard

Component overview

Front



Consisting of:

1i	Door stabiliser
2a	Hinge strip
2g	TIP-ON spacer

A We recommend at least one alignment fitting with a maximum installation height of 3 mm. Alignment fittings that protrude above a height of 3 mm must not be used in the pocket.

**Ordering information**

1	Pocket profile set with TIP-ON		Blum No		Code	
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right	Left	Right
	450	550	801P450E.L2	801P450E.R2	7115146	7115147
	500	600	801P500E.L2	801P500E.R2	7115148	7115149
	600	700	801P600E.L2	801P600E.R2	7115150	7115151
	700	800	801P700E.L2	801P700E.R2	7115152	7115153
	800	900	801P800E.L2	801P800E.R2	7115154	7115155

\* Specification without pocket back. A back construction with a thickness of at least 3 mm is required. Pocket profiles and TIP-ON unit pocket can be shortened to an individual nominal length.

**Consisting of:**

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1d	1 x	TIP-ON unit pocket
1e	5 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip
1h	1 x	BLUMATIC unit
1i	2 x	Door stabiliser: runner profile incl. end cap, black anodised


2	Hinge bracket set		Blum No		Code	
	Pocket height (mm)		Left	Right	Left	Right
	1807 – 1956		801T1000.L2	801T1000.R2	7115156	7115157
	1957 – 2106		801T2000.L2	801T2000.R2	7115158	7115159
	2107 – 2256		801T3000.L2	801T3000.R2	7115160	7115161
	2257 – 2406		801T4000.L2	801T4000.R2	7115162	7115163
	2407 – 2556		801T5000.L2	801T5000.R2	7115164	7115165
	2557 – 2706		801T6000.L2	801T6000.R2	7115166	7115167
	2707 – 2856		801T7000.L2	801T7000.R2	7115168	7115169
	2857 – 2999		801T8000.L2	801T8000.R2	7115170	7115171

Door cover strips must be shortened to a specific length

**Consisting of:**

2a	1 x	Hinge strip, black
2f	1 x	Hinge bracket
2g	1 x	TIP-ON spacer
2h	1 x	TIP-ON incl. catch plate, black
2i	1 x	1 x pocket cover strip incl. 5 x mountings, black anodised
-	29 x	System screws for 1i, 2a and 2g, 6 x 14.5 mm, black

## Ordering information

Pocket connector set							
<b>3</b>	<b>Application with plinth</b>					<b>Blum No</b>	<b>Code</b>
	<b>Pocket side thickness (mm)</b>	<b>Colour</b>			<b>Blum No</b>	<b>Code</b>	
	15 – 19	Black			801V505B	7115172	
Pocket connector top + bottom: POVH 10 mm for 0 – 6 mm gap							
POVH Pocket connector height							
<b>Consisting of:</b>							
<b>3a</b>	<b>2 x</b>	Front pocket connector					
<b>3b</b>	<b>2 x</b>	Back pocket connector					
Pocket connector set							
<b>4</b>	<b>Application without plinth</b>			<b>Blum No</b>		<b>Code</b>	
	<b>Pocket side thickness (mm)</b>	<b>Colour</b>	<b>Left</b>	<b>Right</b>	<b>Left</b>	<b>Right</b>	
	15 – 19	Black	801V605B.L1	801V605B.R1	7115173	7115174	
Pocket connector top: POVH 10 mm for 0 – 6 mm gap							
Pocket connector bottom: POVH 3 mm for gap from 7 – 13 mm							
POVH Pocket connector height							
<b>Consisting of:</b>							
<b>4a</b>	<b>2 x</b>	Front pocket connector					
<b>4b</b>	<b>2 x</b>	Back pocket connector					
Z Accessories							
<b>Scuff guard</b>					<b>Blum No</b>	<b>Code</b>	
	For front thicknesses starting from 23 mm				801ZA00S	7115175	
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection						
<b>Consisting of:</b>							
<b>3 x</b>	External pocket side scuff guard						
Alignment/adjustment fitting for distorted doors						<b>Code</b>	
		Alignment/adjustment fitting – Aluminium <ul style="list-style-type: none"> <li>• For door / front thicknesses of 18-30 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• Length of the adjustment fitting 1990 mm, can be shortened as required.</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>				<b>7113636</b>	
		Alignment/adjustment fitting – Plastic <ul style="list-style-type: none"> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>				<b>7113858</b>	

Please refer to the Lincoln Sentry website for installation instructions and drilling information.

## Ordering information


Z	Accessories			
<b>Screws</b>			<b>Blum No</b>	<b>Code</b>
	6 x 14.5 mm system screws, nickel plated	Pack quantity: 1000	661.1450.HG	7115105
<b>EXPANDO T – for thin fronts</b>			<b>Blum No</b>	<b>Code</b>
	EXPANDO T – single		70T4532T	7102466
EXPANDO T suitable for thin fronts – see page 67				
For front thicknesses less than 18 mm, we recommend a trial application				
Screws are not included in the scope of delivery				
<b>Inter-door support for REVEGO uno + uno</b>			<b>Blum No</b>	<b>Code</b>
			800ZA02S	7115176
<b>Consisting of:</b>				
1 x	Inter-door support (right + left)			

## REVEGO uno + uno Single door, right and left



- Number of fronts: 2
- Installation width: 900 to 1800 mm
- Internal width within the application: up to 1600 mm
- Order all sets for each single door, 1x left and 1x right.

Planning



**Installation depth/pocket depth**

$ET = POT + FS (2\text{ mm}) + FD$

Min. POT = NL + POTV ( $\geq 100\text{ mm}$ ) + PORW ( $\geq 4\text{ mm}$ )

**Installation width/internal width within the application**

$EB = LWA + POB (100\text{ mm})$

$FB = EB - Fsl - Fsr$   
 $Fsl/Fsr = 1.0 - 4.0\text{ mm}$

Max. NL = FB + 8 mm

$FU = FB - NL + 15\text{ mm}$   
 (min. FU = 7 mm)

FD = 18 - 26 mm

- By cutting the profiles to size, the front protrusion (FU) can be customised.
- To ensure optimum functionality, the fronts are slightly tilted inside the pocket.
- A partition side is required for a stand-alone application, or one adjacent to a worktop area.
- A TIP-ON set part no. 956A1004 must be attached in the trigger range for applications with a partition side. We recommend using a screw-on catch plate.
- The internal width within the application determines the maximum width to be planned for the internal construction.
- With front thicknesses (FD) of more than 23 mm, the side gap (pocket side), the outside front radius and the inner radius of the external pocket side must be at least 3 mm.
- For front thicknesses (FD) less than 18 mm (possible depending on material/stability), we recommend a trial application.

EB	Installation width
ET	Installation depth
Fsl	Gap left
Fsr	Gap right
FB	Front width
FD	Front thickness
FS	Front gap
FU	Front protrusion
LWA	Internal width within the application
NL	Nominal length
POB	Pocket width
POT	Pocket depth
PORS	Pocket back cut
PORW	Pocket back
POSD	Pocket side thickness
POTV	Pocket depth loss

Planning


Installation height, front height	
<p><b>Application with plinth</b></p>	<p><math>FH = POH - Fo - Fu</math></p> <p><math>EH \leq POH + POVH \text{ top and bottom}</math></p> <p><math>POH = FH + Fo + Fu</math></p> <p>POVH 10 mm: gap 0 – 6 mm</p> <ul style="list-style-type: none"> <li>- Note tilt angle when erecting!</li> <li>- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm</li> <li>- Minimum plinth height 80 mm</li> </ul>
	<p>EH Installation height</p> <p>Fo Top gap</p> <p>Fu Bottom gap</p> <p>FH Front height</p> <p>POH Pocket height</p> <p>POVH Pocket connector height</p>

Installation height, front height	
<p><b>Application without plinth</b></p>	<p><math>FH = POH - Fo - Fu</math></p> <p><math>EH \leq POH + POVH \text{ top and bottom}</math></p> <p><math>POH = FH + Fo + Fu</math></p> <p>POVH top 10 mm: gap 0 – 6 mm</p> <p>POVH bottom 3 mm: gap from 7 – 13 mm</p> <ul style="list-style-type: none"> <li>- Note tilt angle when erecting!</li> <li>- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm</li> </ul>
	<p>EH Installation height</p> <p>Fo Top gap</p> <p>Fu Bottom gap</p> <p>FH Front height</p> <p>POH Pocket height</p> <p>POVH Pocket connector height</p>


Planning

Application with set-back plinth

Additional rear pocket connector



Inter-door support




- Supports a single door against a double door, two single doors against each other or two double doors against each other

P Pocket

Planning

Internal height and internal depth within the application




LHA = POH
LTA = POT - 35 mm
- The internal height/internal depth within the application determines the maximum height/depth to be planned for the internal construction.
LHA Internal height within the application
LTA Internal depth within the application
POH Pocket height
POT Pocket depth



Installation position	Single door, right or left + double door, right or left (mm)		
	Width	Height	Depth
Installation dimensions	1350 – 2400	1820 – 3012	From 575
Internal dimensions within the application	up to 2150	up to 2884	From 484
Pocket dimensions	100 / 150	1807 – 2999	From 554
Front dimensions	442 – 898/748	1800 – 2980	Thickness 18 – 26
Front weight	35 kg per front		

Overview



EB	Installation width
FB1	Single door front width
FB2	Double door front width
LTB	Track cover panel
POIS	Internal pocket side
PORW	Pocket back
LTR	Track
POH	Pocket height
POT	Pocket depth
ZB	Fixed shelf
2g	TIP-ON spacer
2h	TIP-ON incl. catch plate


**Fittings selection made easy**

It is easy to work out the fittings and drilling positions you need using the Product Configurator. Scan the QR code, enter the webcode in the Product Configurator or click on the short URL. Don't have login information for E-SERVICES yet? Register here and get access free of charge.

**Web code** DQIVXA  
**Link** [www.blum.com/DQIVXA](http://www.blum.com/DQIVXA)

**Product Configurator**

Double door component overview




Consisting of:

1a	Top pocket profile
1b	Bottom pocket profile
1c	Roller profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
2f	Hinge bracket
2i	Pocket cover strip incl. mounting
3a/4a	Front pocket connector
3b/4b	Back pocket connector
Z	Scuff guard

Double door component overview

Front




Consisting of:

2a	Hinge strip
2b	Double door hinge
2c	Roller carriage hinge
2d	TIP-ON unit door
2e	Support for door cover strip
2j	Door cover strip
2k	Mounting for door cover strip
8i	Inter-door support
Z	Inner door support incl. tip-assist

A We recommend at least one alignment fitting per front with a maximum installation height of 20 mm. The space available between the folded pair of fronts is 20 mm.

Double door component overview




Consisting of:

2i	Pocket cover strip incl. mounting
6a	Track
6b	Roller carriage
6c	Roller carriage transporter
6d	Mounting for track cover panels
6e	Catch plate
6f	Spacer
7a	Track fixing
7b	Cover for track fixing
7c	Pin for track fixing
8a	Track extension
8d	Track connection
8e	Cover for track connection
8f	Support angle for depth adjustment

Single door component overview

Pocket



Consisting of:

1a	Top pocket profile
1b	Bottom pocket profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
1h	BLUMATIC unit
2f	Hinge bracket
2i	Pocket cover strip incl. mounting
3a/4a	Front pocket connector
3b/4b	Back pocket connector
Z	Scuff guard

Single door component overview

**Front**

**Consisting of:**

<b>1i</b>	Door stabiliser
<b>2a</b>	Hinge strip
<b>2g</b>	TIP-ON spacer
<b>8i</b>	Inter-door support

A We recommend at least one alignment fitting with a maximum installation height of 3 mm. Alignment fittings that protrude above a height of 3 mm must not be used in the pocket.

## Double door ordering information

1	Pocket profile set with TIP-ON		Blum No		Code	
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right	Left	Right
	450	550	802P450D.L2	802P450D.R2	7115194	7115195
	525	625	802P525D.L2	802P525D.R2	7115196	7115197
	600	700	802P600D.L2	802P600D.R2	7115198	7115199
	675	775	802P675D.L2	802P675D.R2	7115200	7115201
	750	850	802P750D.L2	802P750D.R2	7115202	7115203

\* Specification without pocket back. A back construction with a thickness of at least 3 mm is required. Pocket and roller profiles as well as TIP-ON unit pocket can be shortened to a custom nominal length.

## Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1c	1 x	Roller profile
1d	1 x	TIP-ON unit pocket
1e	6 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip

2	Hinge bracket set with TIP-ON		Blum No		Code	
	Pocket height (mm)		Left	Right	Left	Right
	1807 – 1956		802T1000.L2	802T1000.R2	7115204	7115205
	1957 – 2106		802T2000.L2	802T2000.R2	7115206	7115207
	2107 – 2256		802T3000.L2	802T3000.R2	7115208	7115209
	2257 – 2406		802T4000.L2	802T4000.R2	7115210	7115211
	2407 – 2556		802T5000.L2	802T5000.R2	7115212	7115213
	2557 – 2706		802T6000.L2	802T6000.R2	7115214	7115215
	2707 – 2856		802T7000.L2	802T7000.R2	7115216	7115217
	2857 – 2999		802T8000.L2	802T8000.R2	7115218	7115219

Door cover strips must be shortened to a specific length

## Consisting of:

2a	1 x	Hinge strip
2b	5 x	Double door hinge
2c	1 x	Roller carriage hinge
2d	1 x	TIP-ON unit door
2e	1 x	Support for door cover strip
2f	1 x	Hinge bracket
2i	1 x	Pocket cover strip incl. 5 x mountings, black anodised
2j	1 x	Door cover strip, black anodised
2k	6 x	Mounting for door cover strip

### Double door ordering information

Pocket connector set						
3	Application with plinth			Blum No		Code
	Pocket side thickness (mm)	Colour				
	15 – 17	Black		802V560B	7115220	
	18 – 19	Black		802V580B	7115221	
Pocket connector top + bottom: POVH 10 mm for 0 – 6 mm gap						
POVH Pocket connector height						
Consisting of:						
3a	2 x	Front pocket connector				
3b	2 x	Back pocket connector				

Pocket connector set						
4	Application without plinth			Blum No		Code
	Pocket side thickness (mm)	Colour	Left	Right	Left	Right
	15 – 17	Black	802V660B.L1	802V660B.R1	7115222	7115223
	18 – 19	Black	802V680B.L1	802V680B.R1	7115224	7115225
Pocket connector top: POVH 10 mm for 0 – 6 mm gap						
Pocket connector bottom: POVH 3 mm for gap from 7 – 13 mm						
POVH Pocket connector height						
Consisting of:						
4a	2 x	Front pocket connector				
4b	2 x	Back pocket connector				

6	Track set			Blum No		Code
	LWA2 double door (mm)	Colour	Left	Right	Left	Right
	1050	Black anodised	802L1050DL1	802L1050DR1	7115177	7115178
	1200	Black anodised	802L1200DL1	802L1200DR1	7115179	7115180
	1250	Black anodised	802L1250DL1	802L1250DR1	7115181	7115182
	1350	Black anodised	802L1350DL1	802L1350DR1	7115183	7115184
Track can be shortened to any length.						
LWA2 Internal width within the application, double door						
Consisting of:						
6a	1 x	Track				
6b	1 x	Roller carriage				
6c	1 x	Roller carriage transporter				
6d	2 x	Mounting for track cover panels				
6e	1 x	Catch plate, black				
6f	2 x	Spacer				



**Double door ordering information**

8	Assembly set for a single door and double door combined	Blum No		Code	
		LWA1 single door (mm)	Left	Right	Left
	600	802M6003.L1	802M6003.R1	7115188	7115189
	700	802M7003.L1	802M7003.R1	7115190	7115191
	800	802M8003.L1	802M8003.R1	7115192	7115193

Track extension can be shortened to any length.

LWA1 Internal width within the application, single door

**Consisting of:**

6d	1 x	Mounting for track cover panel
6f	1 x	Spacer
7a	1 x	Track fixing
7b	1 x	Cover for track fixing
7c	2 x	Pin for track fixing
8a	1 x	Track extension
8d	1 x	Track connection
8e	1 x	Cover for track connection
8i	1 x	Inter-door support (right + left)
8f	1 x	Support angle for depth adjustment

**Z Accessories**

Inner door support incl. tip-assist		Blum No	Code
	Supporting length: 218 mm	802ZA030	7115227

For additional support on the worktop area, plinth front, cabinet, etc.

Scuff guard		Blum No	Code
	For front thicknesses starting from 23 mm	802ZA00S	7115226

**Consisting of:**

3 x	External pocket side scuff guard
2 x	Internal pocket side scuff guard

**Double door ordering information**

Z		Accessories	
<b>Screws</b>		<b>Blum No</b>	<b>Code</b>
	6 x 14.5 mm system screws, nickel plated	661.1450.HG	7115105
<b>EXPANDO T – for thin fronts</b>		<b>Blum No</b>	<b>Code</b>
	EXPANDO T – single	70T4532T	7102466
EXPANDO T suitable for thin fronts – see page 67			
For front thicknesses less than 18 mm, we recommend a trial application			
Screws are not included in the scope of delivery			

Alignment/adjustment fitting for distorted doors		Code
	Alignment/adjustment fitting – Aluminium <ul style="list-style-type: none"> <li>• For door / front thicknesses of 18-30 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• Length of the adjustment fitting 1990 mm, can be shortened as required.</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>	7113636
	Alignment/adjustment fitting – Plastic <ul style="list-style-type: none"> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>	7113858

Please refer to the Lincoln Sentry website for installation instructions and drilling information.



Single door ordering information

1	Pocket profile set with TIP-ON		Blum No		Code	
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right	Left	Right
	450	550	801P450E.L2	801P450E.R2	7115146	7115147
	500	600	801P500E.L2	801P500E.R2	7115148	7115149
	600	700	801P600E.L2	801P600E.R2	7115150	7115151
	700	800	801P700E.L2	801P700E.R2	7115152	7115153
	800	900	801P800E.L2	801P800E.R2	7115154	7115155

\* Specification without pocket back. A back construction with a thickness of at least 3 mm is required. Pocket profiles and TIP-ON unit pocket can be shortened to an individual nominal length.

Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1d	1 x	TIP-ON unit pocket
1e	5 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip
1h	1 x	BLUMATIC unit
1i	2 x	Door stabiliser: runner profile incl. end cap, black anodised

2	Hinge bracket set		Blum No		Code	
	Pocket height (mm)		Left	Right	Left	Right
	1807 – 1956		801T1000.L2	801T1000.R2	7115156	7115157
	1957 – 2106		801T2000.L2	801T2000.R2	7115158	7115159
	2107 – 2256		801T3000.L2	801T3000.R2	7115160	7115161
	2257 – 2406		801T4000.L2	801T4000.R2	7115162	7115163
	2407 – 2556		801T5000.L2	801T5000.R2	7115164	7115165
	2557 – 2706		801T6000.L2	801T6000.R2	7115166	7115167
	2707 – 2856		801T7000.L2	801T7000.R2	7115168	7115169
	2857 – 2999		801T8000.L2	801T8000.R2	7115170	7115171

Door cover strips must be shortened to a specific length

Consisting of:

2a	1 x	Hinge strip, black
2f	1 x	Hinge bracket
2g	1 x	TIP-ON spacer
2h	1 x	TIP-ON incl. catch plate, black
2i	1 x	1 x pocket cover strip incl. 5 x mountings, black anodised
-	29 x	System screws for 1i, 2a and 2g, 6 x 14.5 mm, black

Pocket connector set

3	Application with plinth		Blum No	Code
	Pocket side thickness (mm)	Colour		
	15 – 19	Black	801V505B	7115172

Pocket connector top + bottom: POVH 10 mm for 0 – 6 mm gap

POVH Pocket connector height

Consisting of:

3a	2 x	Front pocket connector
3b	2 x	Back pocket connector

**Single door ordering information**

Pocket connector set						
4	Application without plinth		Blum No		Code	
	Pocket side thickness (mm)	Colour	Left	Right	Left	Right
	15 – 19	Black	801V605B.L1	801V605B.R1	7115173	7115174
Pocket connector top: POVH 10 mm for 0 – 6 mm gap						
Pocket connector bottom: POVH 3 mm for gap from 7 – 13 mm						
POVH Pocket connector height						
<b>Consisting of:</b>						
4a	2 x	Front pocket connector				
4b	2 x	Back pocket connector				

**Z Accessories**

Scuff guard			Blum No	Code
	For front thicknesses starting from 23 mm		801ZA00S	7115175
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection			
<b>Consisting of:</b>				
3 x	External pocket side scuff guard			


Screws			Blum No	Code
	6 x 14.5 mm system screws, nickel plated	Pack quantity: 1000	661.1450.HG	7115105

EXPANDO T – for thin fronts			Blum No	Code
	EXPANDO T – single		70T4532T	7102466
EXPANDO T suitable for thin fronts – see page 67				
For front thicknesses less than 18 mm, we recommend a trial application				
Screws are not included in the scope of delivery				

Alignment/adjustment fitting for distorted doors			Code
	Alignment/adjustment fitting – Aluminium <ul style="list-style-type: none"> <li>• For door / front thicknesses of 18-30 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• Length of the adjustment fitting 1990 mm, can be shortened as required.</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>	7113636	
	Alignment/adjustment fitting – Plastic <ul style="list-style-type: none"> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>	7113858	

Please refer to the Lincoln Sentry website for installation instructions and drilling information.

Planning



**Installation width/internal width within the application**

$EB = LWA1 + LWA2 + POB1 (100 \text{ mm}) + POB2 (150 \text{ mm})$

**Front width/front protrusion**

Double door:  $FB = (LWA2 + POB2 - Fsl - Fsm - Fsr) : 2$  (fronts)

Single door:  $FB = LWA1 + POB1 - Fsl - Fsr$

$Fsl/Fsr = 1.0 - 4.0 \text{ mm}$ ;  $Fsm = 2.0 - 8.0 \text{ mm}$

$FU = FB - NL + 15 \text{ mm}$   
(min.  $FU = 7 \text{ mm}$ )

**Installation depth/pocket depth**

$ET = POT + FS (2 \text{ mm}) + FD$

$FD = 18 - 26 \text{ mm}$

Min.  $POT = NL + POTV (\geq 100 \text{ mm}) + PORW (\geq 4 \text{ mm})$

$POSD = 15 - 19 \text{ mm}$

- By cutting the profiles to size, the front protrusion (FU) can be customised.
- To ensure optimum functionality, the fronts are slightly tilted inside the pocket.
- The internal width within the application determines the maximum width to be planned for the internal construction.
- With front thicknesses (FD) of more than 23 mm, the side gap (pocket side), the outside front radius and the inner radius of the external pocket side must be at least 3 mm.
- For front thicknesses (FD) less than 18 mm (possible depending on material/stability), we recommend a trial application.

EB	Installation width
ET	Installation depth
Fsm	Centre gap (between the fronts)
Fsl	Gap left
Fsr	Gap right
FB	Front width
FD	Front thickness
FS	Front gap
FU	Front protrusion
LWA	Internal width within the application
LWA1	Internal width within the application, single door
LWA2	Internal width within the application, double door
NL	Nominal length
POB1	Single door pocket width
POB2	Double door pocket width
POT	Pocket depth
PORS	Pocket back cut
PORW	Pocket back
POSD	Pocket side thickness
POTV	Pocket depth loss

Planning

**Installation height, front height**

**Application with plinth**

$FH = POH - Fo - Fu$	
$EH \leq POH + POVH$ top and bottom	
$POH = FH + Fo + Fu$	
POVH 10 mm: gap 0 – 6 mm	
<ul style="list-style-type: none"> <li>- Note tilt angle when erecting!</li> <li>- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm</li> <li>- Minimum plinth height 80 mm</li> </ul>	
EH	Installation height
Fo	Top gap
Fu	Bottom gap
FH	Front height
POH	Pocket height
POVH	Pocket connector height

**Installation height, front height**

**Application without plinth**

$FH = POH - Fo - Fu$	
$EH \leq POH + POVH$ top and bottom	
$POH = FH + Fo + Fu$	
POVH top 10 mm: gap 0 – 6 mm	
POVH bottom 3 mm: gap from 7 – 13 mm	
<ul style="list-style-type: none"> <li>- Note tilt angle when erecting!</li> <li>- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm</li> </ul>	
EH	Installation height
Fo	Top gap
Fu	Bottom gap
FH	Front height
POH	Pocket height
POVH	Pocket connector height




Planning


Application with set-back plinth

Additional rear pocket connector


REVEGO uno



REVEGO duo




Inter-door support



- Supports a single door against a double door, two single doors against each other or two double doors against each other

P Pocket

Inner door support incl. tip-assist



- Support on the worktop area, plinth front, cabinet, etc.
- Distance to internal installation: 70 – 218/350 mm
- Assembly height of the door support ideally as far down as possible, however up to a maximum height of 1000 mm from the front bottom edge

P Pocket

Planning

**Track installation dimension**

LBH = 83 mm
LBD = 15 - 19 mm (≤ 17 mm the spacer must be used)
LTF = 17 mm
LA = 100 mm
LV = LA + ZBD (≥ 15 mm)
<ul style="list-style-type: none"> <li>- We recommend using a cross member to stabilise the fixed shelf. Minimum distance to front edge of internal pocket side = 170 mm</li> <li>- A solid connection between the fixed shelf and the pocket with connector fittings is recommended for an attractive gap layout</li> <li>- No mounting of add-on parts directly on the track</li> </ul>
FD    Front thickness
LA    Track cut-out
LV    Track installation
LBD   Track cover panel thickness
LBH   Track cover panel height
LTF   Track gap
PORS   Pocket back cut
ZBD   Fixed shelf thickness


**Internal height and internal depth within the application**

LHA = POH - LV
LTA = POT - 70 mm
<ul style="list-style-type: none"> <li>- The internal height/internal depth within the application determines the maximum height/depth to be planned for the internal construction</li> </ul>
LHA   Internal height within the application
LTA   Internal depth within the application
LV    Track installation
POH   Pocket height
POT   Pocket depth



Installation position	Double door right + double door left (mm)		
	Width	Height	Depth
Installation dimensions	1800 – 3000	1820 – 3012	From 575
Internal dimensions within the application	up to 2700	up to 2884	From 484
Pocket dimensions	150	1807 – 2999	From 554
Front dimensions	442 – 748	1800 – 2980	Thickness 18 – 26
Front weight	35 kg per front		

Overview



EB	Installation width
FB	Front width
LTR	Track
LTB	Track cover panel
POH	Pocket height
POT	Pocket depth
POIS	Internal pocket side
PORW	Pocket back
ZB	Fixed shelf

Fittings selection made easy


It is easy to work out the fittings and drilling positions you need using the Product Configurator. Scan the QR code, enter the webcode in the Product Configurator or click on the short URL. Don't have login information for E-SERVICES yet? Register here and get access free of charge.

Web code	DQIVMM
Link	<a href="http://www.blum.com/DQIVMM">www.blum.com/DQIVMM</a>

Product Configurator

**Component overview**

**Pocket**




**Consisting of:**

1a	Top pocket profile
1b	Bottom pocket profile
1c	Roller profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
2f	Hinge bracket
2i	Pocket cover strip incl. mounting
3a/4a	Front pocket connector
3b/4b	Back pocket connector
Z	Scuff guard

Component overview

Front




Consisting of:

2a	Hinge strip
2b	Double door hinge
2c	Roller carriage hinge
2d	TIP-ON unit door
2e	Support for door cover strip
2j	Door cover strip
2k	Mounting for door cover strip
9e	Inter-door support
Z	Inner door support incl. tip-assist

A We recommend at least one alignment fitting per front with a maximum installation height of 20 mm. The space available between the folded pair of fronts is 20 mm.

Component overview

Track



Consisting of:

2i	Pocket cover strip incl. mounting
6a	Track
6b	Roller carriage
6c	Roller carriage transporter
6d	Mounting for track cover panels
6e	Catch plate
6f	Spacer
9a	Track connection
9b	Cover for track connection
9c	Support angle for depth adjustment

## Ordering information

1	Pocket profile set with TIP-ON		Blum No		Code	
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right	Left	Right
	450	550	802P450D.L2	802P450D.R2	7115194	7115195
	525	625	802P525D.L2	802P525D.R2	7115196	7115197
	600	700	802P600D.L2	802P600D.R2	7115198	7115199
	675	775	802P675D.L2	802P675D.R2	7115200	7115201
	750	850	802P750D.L2	802P750D.R2	7115202	7115203

\* Specification without pocket back. A back construction with a thickness of at least 3 mm is required. Order set for each double door, 1x left and 1x right. Pocket and roller profiles as well as TIP-ON unit pocket can be shortened to a custom nominal length.

## Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1c	1 x	Roller profile
1d	1 x	TIP-ON unit pocket
1e	6 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip

2	Hinge bracket set with TIP-ON		Blum No		Code	
	Pocket height (mm)		Left	Right	Left	Right
	1807 – 1956		802T1000.L2	802T1000.R2	7115204	7115205
	1957 – 2106		802T2000.L2	802T2000.R2	7115206	7115207
	2107 – 2256		802T3000.L2	802T3000.R2	7115208	7115209
	2257 – 2406		802T4000.L2	802T4000.R2	7115210	7115211
	2407 – 2556		802T5000.L2	802T5000.R2	7115212	7115213
	2557 – 2706		802T6000.L2	802T6000.R2	7115214	7115215
	2707 – 2856		802T7000.L2	802T7000.R2	7115216	7115217
	2857 – 2999		802T8000.L2	802T8000.R2	7115218	7115219

Order set for each double door, 1x left and 1x right

Door cover strips must be shortened to a specific length

## Consisting of:

2a	1 x	Hinge strip
2b	5 x	Double door hinge
2c	1 x	Roller carriage hinge
2d	1 x	TIP-ON unit door
2e	1 x	Support for door cover strip
2f	1 x	Hinge bracket
2i	1 x	Pocket cover strip incl. 5 x mountings, black anodised
2j	1 x	Door cover strip, black anodised
2k	6 x	Mounting for door cover strip

**Ordering information**

Pocket connector set				
3	Application with plinth			
	Pocket side thickness (mm)	Colour	Blum No	Code
	15 – 17	Black	802V560B	7115220
	18 – 19	Black	802V580B	7115221
Order 1x per double door				
Pocket connector top + bottom: POVH 10 mm for 0 – 6 mm gap				
POVH Pocket connector height				
<b>Consisting of:</b>				
3a	2 x	Front pocket connector		
3b	2 x	Back pocket connector		

Pocket connector set		Blum No		Code		
4	Application without plinth	Left	Right	Left	Right	
	Pocket side thickness (mm)	Colour				
	15 – 17	Black	802V660B.L1	802V660B.R1	7115222	7115223
	18 – 19	Black	802V680B.L1	802V680B.R1	7115224	7115225
Order 1x left and 1x right per double door						
Pocket connector top: POVH 10 mm for 0 – 6 mm gap						
Pocket connector bottom: POVH 3 mm for gap from 7 – 13 mm						
POVH Pocket connector height						
<b>Consisting of:</b>						
4a	2 x	Front pocket connector				
4b	2 x	Back pocket connector				

6	Track set	Blum No		Code		
	LWA2 double door (mm)	Colour	Left	Right	Left	Right
	1050	Black anodised	802L1050DL1	802L1050DR1	7115177	7115178
	1200	Black anodised	802L1200DL1	802L1200DR1	7115179	7115180
	1250	Black anodised	802L1250DL1	802L1250DR1	7115181	7115182
	1350		802L1350DL1	802L1350DR1	7115183	7115184
Order set for each double door, 1x left and 1x right						
Track can be shortened to any length.						
LWA2 Internal width within the application						
<b>Consisting of:</b>						
6a	1 x	Track				
6b	1 x	Roller carriage				
6c	1 x	Roller carriage transporter				
6d	2 x	Mounting for track cover panels				
6e	1 x	Catch plate, black				
6f	2 x	Spacer				



Ordering information


<b>9 Assembly set for two double doors combined</b>				
	<b>Colour</b>		<b>Blum No</b>	<b>Code</b>
	Black		802M0004	7115187
<b>Consisting of:</b>				
<b>9a</b>	<b>1 x</b>	Track connection		
<b>9b</b>	<b>1 x</b>	Cover for track connection		
<b>9c</b>	<b>1 x</b>	Support angle for depth adjustment		
<b>9e</b>	<b>1 x</b>	Inter-door support (right + left)		
<b>Z Accessories</b>				
<b>Inner door support incl. tip-assist</b>			<b>Blum No</b>	<b>Code</b>
	Supporting length: 218 mm		802ZA030	7115227
	For additional support on the worktop area, plinth front, cabinet, etc.			
<b>Scuff guard</b>			<b>Blum No</b>	<b>Code</b>
	For front thicknesses starting from 23 mm		802ZA00S	7115226
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection			
<b>Consisting of:</b>				
<b>3 x</b>	External pocket side scuff guard			
<b>2 x</b>	Internal pocket side scuff guard			
<b>Screws</b>			<b>Blum No</b>	<b>Code</b>
	6 x 14.5 mm system screws, nickel plated		Pack quantity: 1000	661.1450.HG
	7115105			
<b>Alignment/adjustment fitting for distorted doors</b>				<b>Code</b>
	Alignment/adjustment fitting – Aluminium			7113636
	<ul style="list-style-type: none"> <li>• For door / front thicknesses of 18-30 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• Length of the adjustment fitting 1990 mm, can be shortened as required.</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>			
	Alignment/adjustment fitting – Plastic			7113858
	<ul style="list-style-type: none"> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• For door / front panel thicknesses from 16 mm</li> <li>• Maximum door / front panel height 2600 mm</li> <li>• It is recommended that 2 vertical adjustment fittings are installed near the outer edge.</li> </ul>			

Please refer to the Lincoln Sentry website for installation instructions and drilling information.

Ordering information

Z	Accessories	Blum No	Code
<b>EXPANDO T – for thin fronts</b>			
	EXPANDO T – single	70T4532T	7102466
EXPANDO T suitable for thin fronts – see page 67			
For front thicknesses less than 18 mm, we recommend a trial application			
Screws are not included in the scope of delivery			

Planning




<b>Installation width/internal width within the application</b>	EB	Installation width
$EB = 2 \times LWA2 + 2 \times POB$ (150 + 150 mm)	ET	Installation depth
<b>Front width/front protrusion</b>	Fsl	Gap left
$FB = (EB - Fsl - 3 \times Fsm - Fsr) : 4$ (fronts)	Fsr	Gap right
$Fsl/Fsr = 1.0 - 4.0$ mm; $Fsm = 2.0 - 8.0$ mm	Fsm	Centre gap (between the fronts)
Max. NL = FB + 8 mm	FB	Front width
$FU = FB - NL + 15$ mm (min. FU = 7 mm)	FD	Front thickness
<b>Installation depth/pocket depth</b>	FS	Front gap
$ET = POT + FS$ (2 mm) + FD	FU	Front protrusion
FD = 18 – 26 mm	LWA	Internal width within the application
Min. POT = NL + POTV ( $\geq 100$ mm) + PORW ( $\geq 4$ mm)	LWA2	Internal width within the application, double door
POSD = 15 - 19 mm	NL	Nominal length
– By cutting the profiles to size, the front protrusion (FU) can be customised.	POB	Pocket width
– To ensure optimum functionality, the fronts are slightly tilted inside the pocket.	POT	Pocket depth
– The internal width within the application determines the maximum width to be planned for the internal construction.	PORS	Pocket back cut
– With front thicknesses (FD) of more than 23 mm, the side gap (pocket side), the outside front radius and the inner radius of the external pocket side must be at least 3 mm.	PORW	Pocket back
– For front thicknesses (FD) less than 18 mm (possible depending on material/stability), we recommend a trial application.	POSD	Pocket side thickness
	POTV	Pocket depth loss



Planning

Installation height, front height

Application with plinth



$$FH = POH - Fo - Fu$$

$$EH \leq POH + POVH \text{ top and bottom}$$

$$POH = FH + Fo + Fu$$

POVH 10 mm: gap 0 – 6 mm

- Note tilt angle when erecting!
- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm
- Minimum plinth height 80 mm

EH Installation height

Fo Top gap

Fu Bottom gap


FH Front height

POH Pocket height

POVH Pocket connector height

Installation height, front height

Application without plinth



$$FH = POH - Fo - Fu$$

$$EH \leq POH + POVH \text{ top and bottom}$$

$$POH = FH + Fo + Fu$$

POVH top 10 mm: gap 0 – 6 mm

POVH bottom 3 mm: gap from 7 – 13 mm

- Note tilt angle when erecting!
- Minimum distance from the front bottom edge to the floor 10 mm, to the next element above and below 6 mm

EH Installation height

Fo Top gap

Fu Bottom gap


FH Front height

POH Pocket height

POVH Pocket connector height


Application with set-back plinth

Additional rear pocket connector



**Planning**


**Inter-door support**



- Supports a single door against a double door, two single doors against each other or two double doors against each other

P Pocket

**Inner door support**




- Support on the worktop area, plinth front, cabinet, etc.
- Distance to internal installation: 70 – 218/350 mm
- Assembly height of the door support ideally as far down as possible, however up to a maximum height of 1000 mm from the front bottom edge

P Pocket



Planning


Track installation dimension



LBH = 83 mm	
LBH = 15 - 19 mm (≤ 17 mm the spacer must be used)	
LTF = 17 mm	
LA = 100 mm	
LV = LA + ZBD (≥ 15 mm)	
<ul style="list-style-type: none"> <li>- We recommend using a cross member to stabilise the fixed shelf. Minimum distance to front edge of internal pocket side = 170 mm</li> <li>- A solid connection between the fixed shelf and the pocket with connector fittings is recommended for an attractive gap layout</li> <li>- No mounting of add-on parts directly on the track</li> </ul>	
FD	Front thickness
LA	Track cut-out
LV	Track installation
LBD	Track cover panel thickness
LBH	Track cover panel height
LTF	Track gap
PORS	Pocket back cut
ZBD	Fixed shelf thickness

Planning

Internal height and internal depth within the application



$$LHA = POH - LV$$

$$LTA = POT - 70 \text{ mm}$$

- The internal height/internal depth within the application determines the maximum height/depth to be planned for the internal construction

LHA Internal height within the application

LTA Internal depth within the application

LV Track installation

POH Pocket height

POT Pocket depth



**Product Configurator**

Obtain the exact calculation for assembling the cut-to-size profiles quickly and efficiently using the Product Configurator. The configurator calculates all the dimensions for each configuration and also outputs them as drawings.




[www.blum.com/revpc](http://www.blum.com/revpc)

**Calculations and assembly of the profiles**

**REVEGO duo | Double door**

**Pocket cover strip, door cover strip**




FH	Front height
L	Left
R	Right
POH	Pocket height
2i	Pocket cover strip
2j	Door cover strip

## Calculations and assembly of the profiles

### REVEGO duo | Double door

Roller profile, pocket profile, TIP-ON unit pocket



$$NL = POT - POTV - PORW$$

#P1	1a	Top pocket profile
#P2	1c	Roller profile
#P3	1d	TIP-ON unit pocket
#P5	1b	Bottom pocket profile

NL	Nominal length
POT	Pocket depth
PORW	Pocket back
POTV	Pocket depth loss


**Note**

- Pocket and roller profiles as well as TIP-ON unit pocket must not be damaged during cutting to size.
- Pocket and roller profiles as well as TIP-ON unit pocket must be cleaned to remove any dirt and deburred before installation.

Calculations and assembly of the profiles

REVEGO uno | Single door

Pocket cover strip




Fo	Top gap
Fu	Bottom gap
POH	Pocket height
L	Left
R	Right
2i	Pocket cover strip

Calculations and assembly of the profiles

REVEGO uno | Single door

Pocket profile, TIP-ON unit pocket, door stabiliser



$NL = POT - POTV - PORW$

#P1	1a	Top pocket profile
#P3	1d	TIP-ON unit pocket
#P5	1b	Bottom pocket profile
	1i	Door stabiliser

NL	Nominal length
POT	Pocket depth
PORW	Pocket back
POTV	Pocket depth loss


Note

- Pocket profiles, TIP-ON unit pocket and door stabiliser must not be damaged during cutting to size.
- Pocket profiles, TIP-ON unit pocket and door stabiliser must be cleaned to remove any dirt and deburred before installation.

Calculations and assembly of the profiles

REVEGO duo | Double door

Track, track extension



Application	X	Y
REVEGO duo	-	LWA - 12 mm
REVEGO uno + duo	LWA1 - 58 mm	LWA2 - 12 mm
REVEGO duo + duo	-	LWA2 - 12 mm

- LWA Internal width within the application
- LWA1 Internal width within the application, single door
- LWA2 Internal width within the application, double door
- 6a Track
- 8a Track extension


**EXPANDO T**



- EXPANDO T – fixing system
- Thin fronts of 8 mm or more
- Different front materials

EXPANDO T – single				
	Colour	Material	Blum No	Code
	Dark grey	Nylon/steel	70T4532T	7102466

**Drilling depth | Screw selection – EXPANDO T**




Screws with M4 thread have to be used for EXPANDO T single

The lowest possible drilling depth should be selected for the single dowel depending on the screw length

BT Drilling depth  
 ES Screw penetration depth  
 ES min. = 4 mm  
 ES max. = BT - 0.5 mm  
 \* Stone and ceramic +0.2/-0.1 mm

**Assembly – EXPANDO T**



Area of application and assembly recommendation		
EXPANDO T is suitable for fixing Blum fittings to thin cabinet fronts of all types of materials. Front materials can be just 8 mm thick or more, provided they are sufficiently stable and strong.	<b>Materials tested by Blum</b>	<b>Nm</b>
	Chipboard (transverse tensile strength > 0.4 N/mm <sup>2</sup> )	1.5
Nm Minimum tightening torque	MDF (transverse tensile strength > 0.6 N/mm <sup>2</sup> )	1.5
	HDF	2
	HPL	2
	Mineral composites	2
		3
	Artificial stone – quartz composite	3
	Ceramic panels	3

**Limitation of liability**

Blum accepts no liability for the use of EXPANDO T in combination with materials not listed or fittings from other manufacturers. It is recommended that assembly be carried out by an experienced furniture manufacturer.

**Gauge set for REVEGO pocket connector**



- Drilling template for horizontal drillings on REVEGO pocket connectors on the pocket side panel
- Material: nylon/steel/aluminium

Ordering information	Blum No	Code
	STL.8000	7115229

**Blum screwdrivers**

Ordering information	Type:	Length:	Code
	Torx TX2	35mm	7102541
	Torx TX2	100mm	7102540
	Pozi	100mm	7102539

**Internal testing and inspection regulations**

<b>Durability</b>		40,000 opening and closing cycles.
<b>Abuse test</b>		Horizontal load test for securing unintended overload
<b>Slam open/slam shut test</b>		To simulate overload when opening and closing and ensure that the fronts do not detach from fittings.
<b>Corrosion test</b>		Based on DIN EN ISO 9227 and DIN EN ISO 6270-2 for simulating corrosion influences.



[www.lincolnsentry.com.au/page/blum-revego](http://www.lincolnsentry.com.au/page/blum-revego)

National Customer Support Centre  
Ph: 1300 551 919

[www.lincolnsentry.com.au](http://www.lincolnsentry.com.au)



#### Get Social

-  @lincolnsentry
-  @lincolnsentry
-  Lincoln Sentry Group Pty. Ltd

 **LINCOLN**<sup>®</sup>  
S E N T R Y

Lincoln Sentry logo is a registered trade mark of Lincoln Sentry Group Pty. Ltd.  
All images in this brochure are copyrighted © BLUM

BR0174CH